

F4 MONRO-JET

Exploded View




Figure 3 Types F3, F4 & F6

PARTS BREAKDOWN

Number	Amount	Description
1	1	Nozzle body
2	1	Inlet cover
3	1	Driving tube (seat)
4	1	Rotor
5	1	Seat (nose)
6	1	O-ring
7	1	O-ring
8	1	O-ring

NOTE: Parts not sold separately, available in kits only.