


WIRING DIAGRAM FOR RHINO PRESSURE WASHER



## List of components

Tag (-)	Code	Description	Constructor	Page	Column
S1	70.000.022	Gasoil Float		2	3
A1				2	3
Y1	50.000.024	Solenoid Valve		2	3
K1	70.000.014	Thermostat		2	3
S2	70.000.035	Pressure Switch		2	3
H1	70.000.116	Orange Light		2	4
T1	70.000.019	HT Transformer		2	5
M1	50.000.221	Burner Motor		2	5
SR1	70.000.011	Electronic Board		2	6
Q1	70.000.044	Two-way Switch		2	6
F1	70.000.074	Fuse 32A		2	7
A2				2	7
S3	70.000.035	Pressure Switch		2	7
K2	70.000.009	Contactactor		2	7
T2	70.000.010	Transformer 0-24V		2	7
F2	70.000.060	Fuse 3.1A		2	7
F3	70.000.042	Thermic Relay		2	8
M2	60.000.000	Single Phase Motor		2	8